

LEADER ARM OPERATING INSTRUCTIONS

Height Control:

1. Grab the platform and tilt it slightly upwards to unlock.
2. While still holding the platform slightly tilted, adjust to the desired height.
3. Release the platform to lock in position.



Tilt Control:

1. To adjust tilt simply rotate the knob until the desired angle is achieved.

