

# ASSEMBLY INSTRUCTIONS



- 1) Place the seat base (A) on the ground.
- 2) Insert the thick end of the gas cylinder (B) into the base.
- 3) Line up the mounting hole of the mechanism (C) to the top end of the gas cylinder and place the seat and back assembly (D) onto the gas cylinder

# USER INSTRUCTIONS



## **Adjusting seat height**

- 1) Lift lever I
- 2) Adjust seat to desired height
- 3) Release lever I to lock the seat height

## **Adjusting seat angle**

- 1) Raise lever II to unlock the seat pan
- 2) Adjust seat pan to the desired angle
- 3) Lower lever II to lock the seat pan at the desired angle

## **Adjusting back height**

- 1) Loosen knob III counterclockwise
- 2) Adjust back rest height to the desired position
- 3) Tighten knob III to lock the back height

## **Adjusting back tilt**

- 1) Raise lever IV to unlock back tilt
- 2) Adjust the back rest to the desired angle
- 3) Lower lever IV to lock the back tilt